Quick reference guide: Comparing the DB25 <u>ANALOG</u> Audio Pin-configurations of various D-Cinema servers, processors, and D-to-A converters. (Both 6-channel and 8-channel analog).

NOTE: The information in this document was compiled over time from manufacturer's equipment manuals and service calls, and is used internally by Odyssey for construction of cables and other devices. It is a guide only.

It is your responsibility to verify the accuracy of any information you may derive from this document. Of course, please let us know if you notice any errors or omissions.

This document covers the various Dsub-25 ("DB-25") analog audio pinouts used in our industry. Some of these may have more official titles, but below are the names we use to identify the standards:

- The "Dolby/DA20" pin-configuration. Usually a 6-channel unbalanced pattern.
- The "Dolby/DMA8/ECI-60" pin-configuration. An 8-channel balanced pattern.
- The "Doremi" pin-configuration. An 8-channel unbalanced pattern.
- The "THX/Sony" pin-configuration. An 8-channel balanced pattern.
- The "TASCAM/ATMOS" pin-configuration. An 8-channel balanced pattern.

<u>Devices OUTPUTS with DB25 "DA20" unbalance analog pinout:</u>

Qube XPE and XPS servers. The manual says "DB25 Male", presumably on the chassis. **DTS Media players DTS-XD10 and XD20**

Device OUTPUTS with DB25 "DMA8" balanced analog pinout:

DMA8/DMA8plus

ECI-60

NOTE: male connector on chassis.

NOTE: female connector on chassis.

Processor INPUTS with DB25 "DA20" pinout that allow direct DB25 cable connection from the above outputs:

CP500 (6-channel only, unbalanced)
CP650 (6-channel only, unbalanced)
JSD-80 (USL) (up to 8-channels in, unbalanced)
DTS-XD10P (up to 8-channels in, unbalanced)
Enpar DCP800D (up to 8-channels in, unbalanced)

Processors INPUTS with DB25 "**THX**" input analog pinouts:

QSC DCP-100, DCP-200, DCP-300 Input only (Main Analog Input). No DB25 output. QSC DPM series Input only (Analog Inputs). No DB25 output.

Processors with "THX" analog pinouts for both INPUT and OUTPUT:

CP750 Female input, male output connectors on chassis.

JSD-60 (USL) Female input, male output connectors on chassis. **NOTE**: 6-channel input only.

JSD-100 Female input, male output connectors on chassis.

SKA-3D (Christie) Female input, male output connectors on chassis.

DATASAT AP20/24 NOTE: up to 3 input DB25's and 3 output DB25's

Sony DFP-D3000 Female input, male output connectors on chassis.

Female input, male output connectors on chassis.

Processors with "TASCAM" analog pinouts for inputs and outputs:

CP-850 and DAC3202 TASCAM output connectors (Mappable) **Trinnov Ovation / Ovation2** One analog input and 3 analog output connectors

Odyssey offers boards that provide a compatible DB25-female input connector for older CP's with screw terminals, or with incompatible older Dsub pinouts, and with the newer "THX" style 8-channel input pinouts.

Odyssey boards that provide "**DA20**" or "**ECI-60**"-style DB25 input connectors for older processors:

INPUT25-55 for **CP55** (modified and unmodified for split stereo surrounds)

INPUT25-65 for **CP65**

4FJS-XF for **USL JS**-series processors (This board has isolation transformers.)

INPUT25-6AD for **DTS-6AD** (correctly matches up all of the minuses)

INPUT25-3K for **Sony DFP-D3000 and DCP-1000** (For 6-channels. Can be ordered for 8-channels.)

INPUT25-2C for **Smart Mod IIC**, and **Mod's 5** through **8**.

4F2C-XF-DA transformer isolation for **Smart Mod IIC**, and **Mod's 5** through **8**.

4F2B-XF transformer isolation for **Smart Mod IIB**.

Odyssey boards that provide "DMA8/ECI-60/DAX-602" -style DB25 input connectors for NEWER processors with

the "THX"-style input pin-configurations:

INPUT25-JSD100 for USL JSD-100 (for up to 8-channels)
ODY-ECITHX-8 for QSC DCP-100/200/300 (for up to 8-channels)
ODY-ECITHX-8 for CP750, and Christie SKA-3D (for up to 8-channels)

TASCAM:

Odyssey also provides boards that convert between THX and TASCAM pinouts.

Regarding Doremi analog audio:

"Classic" **Doremi** servers (those that were equipped with the <u>analog</u> output board) and **Doremi AUD-D2A** converters have a <u>proprietary</u> analog d-sub pin-configuration. Custom cabling is usually required to connect these to cinema processors.

	"DA20" -style Pin-configuration	"DMA8" -style Pin-configuration
	(6-channel, un-balanced)	(8-channel, balanced)
1	Analog Ground	1 Left (-)
2	Right Surround (+)	2 Right Surround (+)
3	Analog Ground	3 Right Surround (-)
4	Analog Ground	4 Left Surround (-)
5	Analog Ground	5 Right CENTER (-)
6	Analog Ground	6 Right (-)
7	Analog Ground	7 Left CENTER (-)
8	Analog Ground	8 Center (-)
9	Analog Ground	9 Analog Ground (chassis gnd DMA8)
10	Analog Ground	10 Analog Ground (chassis gnd DMA8)
11	Analog Ground	11 Analog Ground (chassis gnd DMA8)
12	Analog Ground	12 Subwoofer (-)
13	Analog Ground	13 Analog Ground (chassis gnd DMA8)
14	Left (+)	14 Left (+)
15	Left Surround (+)	15 Left Surround (+)
16	Analog Ground/ (RC+ on JSD-80)	16 Right CENTER (+)
17	Right (+)	17 Right (+)
18	Analog Ground/ (LC+ on JSD-80)	18 Left CENTER (+)
19	Analog Ground	19 CHASSIS Ground
20	Center (+)	20 Center (+)
21	Analog Ground/ (sometimes n/c)	21 (sometimes n/c)
22	Analog Ground	22 Analog Ground (n/c on DMA8 out)
23	Analog Ground	23 Analog Ground (n/c on DMA8 out)
24	Subwoofer (+)	24 Subwoofer (+)
25	Analog Ground/ (sometimes n/c)	25 ("pass-through" on D/A converters)
	Devices with this input	Devices with this input
	pin-configuration:	pin-configuration:
	-	
CP5	00	Odyssey INPUT25-6AD (NO LC or RC)
CP6	50	Odyssey INPUT25-3K board
JSD-	80	Odyssey INPUT25-JSD100 board
DTS	XD10P	Odyssey ODY-ECITHX-8 board
Odys	ssey INPUT25-55 board.	
	ssey INPUT25-65 board.	
	ssey 4FXF-series transformer bds.	
	•	

	"Doremi" -style Pin-configuration			
	(8-channel, un-balanced output)			
1	(Ch.8) Right Center (+)			
3	(Ch.8) Right Center Ground			
	n/c			
4	(Ch.6) Right Surround (+)			
5	(Ch.6) Right Surround Ground			
	n/c			
7	(Ch.4) Subwoofer (+)			
8	(Ch.4) Subwoofer Ground			
9	n/c			
10	(Ch.2) Right (+)			
11	(Ch.2) Right Ground			
12	n/c			
13	n/c			
14	n/c			
15	(Ch.7) Left Center (+)			
16	(Ch.7) Left Center Ground			
17	n/c			
18	(Ch.5) Left Surround (+)			
19	(Ch.5) Left Surround Ground			
20	n/c			
21	(Ch.3) Center (+)			
22	(Ch.3) Center Ground			
23	n/c			
24	(Ch.1) Left (+)			
25	(Ch.1) Left Ground			

Devices with this pin-configuration:

Doremi Servers (w/DB25 output) (with the internal Analog output board)

Doremi AUD-D2A digital-to-analog converter output.

NOTE: According the Doremi audio wiring guide:

Never, Never, EVER attach a shield to the Doremi end of an analog cable.

	"THX" –style Pin-configuration			
	(8-channel, balanced)			
	(o mamon baranood)			
1	Ground			
2	Left (+)			
3	Left Center (-)			
4	Ground			
5	Center (+)			
6	Right Center (-)			
7	Ground			
8	Right (+)			
9	Ground			
10	Left Surround (-)			
11	Right Surround (-)			
12	Subwoofer (-)			
13	Ground			
14	Left (-)			
15	Ground			
16	Left Center (+)			
17	Center (-)			
18	Ground			
19	Right Center (+)			
20	Right (-)			
21	n/c			
22	Ground			
23	Left Surround (+)			
24	Right Surround (+)			
25	Subwoofer (+)			

Devices with this input pin-configuration:

CP750

USL JSD-100

USL JSD-60 (in=6-channel, out=8-channel)

Christie SKA-3D Sony DCP-1000 Sony DFP-D3000

(NOTE: The above processors have the same input <u>AND</u> output analog pinouts.)

QSC DCP-100/200/300 (Input only) QSC DPM series processors (input only)

Also: - QSC DCM-series monitors

- USL monitors
- Odyssey monitors and crossovers
- THX monitors
- Others

	"TASCAM" –style Pin-		TASCAM" –style Pin-configuration	
	configuration (8-channel, balanced output)		(8-channel, balanced output) Channels 9-16	
1	Ch.8 (+)	1	Ch.16 (+)	
2	Ch.8 Ground	2	Ch.16 Ground	
3	Ch.7 (-)	3	Ch.15 (-)	
4	Ch.6 (+)	4	Ch.14 (+)	
5	Ch.6 Ground	5	Ch.14 Ground	
6	Ch.5 (-)	6	Ch.13 (-)	
7	Ch.4 (+)	7	Ch.12 (+)	
8	Ch.4 Ground	8	Ch.12 Ground	
9	Ch.3 (-)	9	Ch.11 (-)	
10	Ch.2 (+)	10	Ch.10 (+)	
11	Ch.2 Ground	11	Ch.10 Ground	
12	Ch.1 (-)	12	Ch.9 (-)	
13	n/c	13	n/c	
14	Ch.8 (-)	14	Ch.16 (-)	
15	Ch.7 (+)	15	Ch.15 (+)	
16	Ch.7 Ground	16	Ch.15 Ground	
17	Ch.6 (-)	17	Ch.14 (-)	
18	Ch.5 (+)	18	Ch.13 (+)	
19	Ch.5 Ground	19	Ch.13 Ground	
20	Ch.4 (-)	20	Ch.12 (-)	
21	Ch.3 (+)	21	Ch.11 (+)	
22	Ch.3 Ground	22	Ch.11 Ground	
23	Ch.2 (-)	23	Ch.10 (-)	
24	Ch.1 (+)	24	Ch.9 (+)	
25	Ch.1 Ground	_25_	Ch.9 Ground	
	Devices with this		Devices with this	
	pin-configuration:		pin-configuration:	
* Dolby CP850 output * Dolby DAC3201, 3202		* Dolby CP850 "Channels 9-16" output		
* Trinnov Ovation / Ovation2			* A third connector would carry channels 17-24 (Trinnov and DAC's)	
* Other devices with a published "TASCAM" analog audio pinout.			* A fourth connector would carry channels 25-32. (DAC 3201 and 3202)	